



## Condé Systems Cartridge Recycle Program

Return your used qualifying ink cartridges for a \$5 account credit or we will donate \$5 in your name to one of the following charities: American Red Cross, American Cancer Society or UNICEF.

We accept back all of the following cartridges for Epson printers: ArTainium™, SubliJet™, ChromaBlast™ or MultINK™ cartridges, refillable or non-refillable. (We cannot take Epson OEM cartridges or cartridges for any other printer, sorry.)

Contact your Condé Account Manager at 1-800-826-6332 to start the Recycle Credit program!

Please include this form in the box you mail with your used cartridges:

Please credit my account # \_\_\_\_\_

Please credit this charity:

American Red Cross     
  American Cancer Society     
  UNICEF

**Please Print:**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

City: \_\_\_\_\_ St: \_\_\_\_\_ ZIP: \_\_\_\_\_

Phone: (\_\_\_\_) \_\_\_\_\_ - \_\_\_\_\_

If you choose to donate to a charity, a tax receipt will be provided.  
Credits to your Condé Account will show up when posted.



Mailing Label:

FROM \_\_\_\_\_

\_\_\_\_\_

**Condé Systems, Inc.**  
 Recycling Center  
 5600 Commerce Blvd. East  
 Mobile, AL 36619-9214

## New Product Spotlight



Select from  
white, ivory, blue,  
green, & burgundy.

## DyeTrans™ Image Towels™

These new cotton terry cloth towels provide wonderfully absorbent softness and feature a sublimatable polyester strip for customization. Using a DyeTrans Sublimation System, photographic images can be transferred onto the strip - allowing digital decorators to create a customized towel that is an immediate favorite!



Great for any gift giving occasion...

- Baby Shower
- Birthday
- Wedding
- Housewarming
- Sports Team
- Promotional
- Christmas
- Anniversary
- School Graduation
- Corporate
- And More!

### Pressing Instructions:

*The Conde DyeTrans Image Towel has a sublimatable strip that runs the width of the front of the towel. For best results, first pre-press this strip for about 30 seconds. This procedure will yield a consistently flat area on and around the strip. Next, trim your Jetcol high-release transfer paper to the size of the strip with a slight bleed area to account for possible shifting of the transfer during pressing. You will then need to "liberally" apply Conde ProSpray aerosol adhesive to the transfer paper. Remember to allow time (approximately 30 seconds) for the ProSpray to set-up on the transfer before placing it on the towel.*

*While not required, many prefer to raise the imaging area of textile substrates, such as wallets, tote bags, shirts, aprons, pillowcases and towels, prior to transfer. You can do this with a custom-cut piece of metal, heat conductive rubber pad or Nomex felt.*

*Place the towel, strip facing up and transfer facing down, onto the lower rubber platen. A protective piece of paper or Teflon should be placed onto the lower rubber platen and on top of the transfer. Set the press to 365°F, medium-to-heavy pressure, 30 second pre-heat, and dwell time to 65 seconds. After sublimation, gently raise the press and peel the transfer from the towel using a single swift motion. This should reveal a fantastic and durable final product for all to admire.*



*Delivering all the value of today's color output technology.™*

Condé Systems, Inc. • 5600 Commerce Boulevard East • Mobile, Alabama 36619  
toll free: 800.826.6332 • phone: 251.633.5704 • fax: 251.633.3876 • email: sales@conde.com

**www.conde.com**